

VirusGEN[®] AAV Transfection Kit with RevIT[™] AAV Enhancer



Protocol for MIR 8007, 8008

Quick Reference Protocol, SDS and Certificate of Analysis available at mirusbio.com/8007

INTRODUCTION

Adeno-associated virus (AAV) is a nonenveloped, single stranded DNA virus from the *Parvoviridae* family notable for its lack of pathogenicity, low immunogenicity and ability to infect both dividing and quiescent cells. Because AAV is replication-defective in the absence of adeno or helper proteins and is not implicated in any known human diseases, it is widely considered a safe gene delivery vehicle for *in vivo* and *in vitro* applications. Accordingly, recombinant AAV has become an invaluable tool for gene therapy and the creation of isogenic human disease models.

The TransIT-VirusGEN[®] Transfection Reagent enables the generation of high titer AAV in HEK 293 cell types. The VirusGEN[®] AAV Transfection Kit with RevIT[™] AAV Enhancer further enhances the performance of TransIT-VirusGEN[®] Transfection Reagent through the addition of the proprietary RevIT[™] AAV Enhancer. The VirusGEN[®] AAV Transfection Kit with RevIT[™] AAV Enhancer is ideal for generating high titer AAV preparations to accelerate research and development.

SPECIFICATIONS

Storage	Store TransIT-VirusGEN [®] Reagent -10 to -30°C, tightly capped. Store RevIT [™] AAV Enhancer at -10 to -30°C, tightly capped. Before each use , warm to room temperature and vortex gently. Do not freeze/thaw RevIT[™] AAV Enhancer > 5 times.
Stability / Guarantee	When properly stored and handled, TransIT-VirusGEN [®] Transfection Reagent is guaranteed for 1 year from the date of purchase, and RevIT [™] AAV Enhancer is guaranteed for 6 months from the date of purchase.



Warm TransIT-VirusGEN[®] Reagent and RevIT[™] AAV Enhancer to room temperature before each use. Mix gently.

MATERIALS

Materials Supplied

The VirusGEN[®] AAV Transfection Kit with RevIT[™] AAV Enhancer is supplied in **one** of the following formats:

Product No.	Volume of TransIT-VirusGEN [®] Transfection Reagent	Volume of RevIT [™] AAV Enhancer
MIR 8007	2 × 1.5 mL	1 × 1.5 mL
MIR 8008	1 × 30 mL	10 × 1.5 mL

For Research Use Only

BEFORE YOU START:

Important Tips for Optimal AAV Production

The suggestions below yield high efficiency plasmid DNA transfection using the VirusGEN® AAV Transfection Kit with RevIT™ AAV Enhancer.

- **Cell culture conditions.** Use suspension HEK 293 cells with the VirusGEN® AAV Transfection Kit with RevIT™ AAV Enhancer. Before transfection, ensure cells are $\geq 95\%$ viable by trypan blue exclusion (or similar method) and doubling every 24 hours. After transfection, there is no need to perform a medium change to remove the transfection complexes.
- **Cell density at transfection.** The recommended cell density is 3×10^6 cells/ml. Passage cells 18-24 hours before transfection to ensure that cells are actively dividing and reach the appropriate density at time of transfection.
- **AAV packaging and transfer plasmids.** The optimal ratio between plasmids will depend on the vector backbone and gene-of-interest. For each unique construct, empirically determine and use the optimal ratio for best results. Use plasmid manufacturer recommendations or previously established ratios as a starting point.
- **RevIT™ AAV Enhancer.** Titrate RevIT™ AAV Enhancer from 0.5 to 1.5 μ l per 1 ml of culture to determine the optimal amount for production of your specific viral vector.
- **Ratio of TransIT-VirusGEN® to DNA.** Determine the optimal TransIT-VirusGEN® Reagent:DNA ratio for each cell type by varying the amount of reagent from 1.5-3 μ l per 1-2 μ g total DNA. Refer to **Table 1** for recommended starting conditions based on culture size.
- **Complex formation conditions.** Prepare TransIT-VirusGEN® Reagent:RevIT™ AAV Enhancer:DNA complexes in PBS or compatible basal cell culture media in a volume that is 5-10% of the total culture volume. We recommend a complex formation time of 15-45 minutes. If forming complexes in a volume that is less than 5-10% of the total culture volume, complex formation time may need adjustments.




Premix packaging and transfer plasmids together prior to adding to the complex formation medium.



Do not use serum or antibiotics in the media during transfection complex formation.

Transfection complexes can be added directly to cells cultured in growth media +/- serum and up to 0.1-1X antibiotics.

VirusGEN® AAV Transfection Kit with RevIT™ AAV Enhancer Workflow:



VirusGEN® AAV Transfection Kit with RevIT™ AAV Enhancer Workflow

NOTE: Use of the VirusGEN® AAV Transfection Kit with RevIT™ AAV Enhancer is only recommended for AAV production in suspension HEK 293 cell lines. Contact Mirus Bio Technical Support for optimization in adherent cell culture platforms.

The following procedure describes plasmid DNA transfections for AAV generation in 125 ml Erlenmeyer shake flasks using 30 ml of complete growth medium. If using an alternate cell culture vessel, increase or decrease the amounts of serum-free complex medium, *TransIT-VirusGEN®* Reagent, *RevIT™* AAV Enhancer and total DNA based on the **volume of complete growth medium** to be used. To calculate the required reagent quantities based on the recommended starting conditions and total culture volume, refer to the calculation worksheet in **Table 1** (below).

Table 1. Scaling worksheet for *TransIT-VirusGEN®* with *RevIT™* AAV Enhancer

Starting conditions per milliliter of complete growth medium				
	Per 1 ml		Total culture volume	Reagent quantities
PBS or basal medium	0.1 ml	×	_____ ml	= _____ ml
Total Plasmid DNA (1 µg/µl stock)	2 µl	×	_____ ml	= _____ µl
<i>TransIT-VirusGEN®</i> Reagent	3 µl	×	_____ ml	= _____ µl
<i>RevIT™</i> AAV Enhancer	1 µl	×	_____ ml	= _____ µl

NOTE: Total Plasmid DNA refers to the combined weight of AAV plasmids (in µg) per transfection.

Materials Required but Not Supplied

- Suspension HEK 293 Cells (e.g. Viral Production Cells 2.0, Gibco Cat. No. A49784)
- Complete Culture Medium (e.g. Viral Production Medium, Gibco Cat. No. A4817901 or BalanCD HEK293, Irvine Scientific Cat. No. 91165)
- Plasmid DNA (e.g. Agilent AAV2 pDNA: pAAV-hrGFP (Cat. No. 240074-51), pAAV-RC (Cat. No. 240071-53), pHelper (Cat. No. 240071-54))
- Phosphate Buffered Saline (PBS) (e.g. Millipore Sigma Cat. No. D8537)
- Erlenmeyer shake flasks (e.g. Corning® Cat. No. 431143 or Thomson Cat. No. 931110)
- 10X Cell Lysis Buffer (500 mM Tris pH 8, 10% Tween® 20, 20 mM MgCl₂)
- 5 M Sodium Chloride (5 M NaCl)
- Benzonase® or equivalent (e.g. Sigma Cat. No. E1014 or Syd Labs Cat. No. BP4200)

Transient Plasmid Transfection Protocol per 30 ml HEK 293 Culture

A. Maintenance of cells

1. Passage suspension HEK 293 cells 18-24 hours prior to transfection to ensure that cells are actively dividing at the time of transfection and to obtain a density of $3 - 4 \times 10^6$ cells/ml the next day.

NOTE: Perform cell counts and evaluate viability daily to ensure that cells are doubling every 24 hours and $\geq 95\%$ viable by trypan blue exclusion. DO NOT proceed with transfection if cells are not doubling normally or are $< 95\%$ viable.

2. Incubate cells overnight under appropriate conditions (e.g. 37°C, 5-8% CO₂, shaking).

B. Prepare *TransIT-VirusGEN®:RevIT™ AAV Enhancer:DNA complexes* (immediately before transfection)

1. Warm *TransIT-VirusGEN®* Reagent and *RevIT™* AAV Enhancer to room temperature and vortex gently before using.
2. Immediately prior to transfection, seed cells at a density of 3×10^6 cells/ml into a transfection culture vessel (e.g. 30 ml per 125 ml Erlenmeyer shake flask).
3. Place 3 ml of PBS in a sterile tube.
4. In a separate sterile tube, combine AAV plasmids per manufacturer recommendations to a final concentration of 1 µg/µl. Mix thoroughly.
5. Transfer 60 µl of the DNA mixture prepared in Step B.4 to the tube containing PBS. Mix completely.
6. Add 30 µl of *RevIT™* AAV Enhancer to the diluted DNA and PBS. Mix completely.
7. Add 90 µl of *TransIT-VirusGEN®* Reagent to the diluted DNA:*RevIT™* mixture. Mix completely by inversion or vortexing. **Do NOT** agitate *TransIT-VirusGEN®:RevIT™:DNA* complexes again after this initial mixing.
8. Incubate at room temperature for 15 - 45 minutes without additional agitation to allow transfection complexes to form.

C. Distribute the complexes to cells in complete growth medium

1. Add the *TransIT-VirusGEN®:RevIT™ AAV Enhancer:DNA complexes* (prepared in Step B) to culture vessel, swirling gently to distribute.
2. Shake flasks on an orbital shaker (125 rpm when using a shaker with a 1.9 cm orbital throw) at appropriate temperature and CO₂ levels (e.g. 37°C, 5-8% CO₂).
3. Incubate cultures for 48-72 hours prior to AAV harvest.

D. Harvest and storage of AAV

1. Following the 48-72 hour incubation, transfer the total volume of cell suspension (i.e. 33 ml) to a sterile conical tube or appropriate vessel.
2. Add 0.1X volume of 10X Cell Lysis Buffer (i.e. 3.3 ml) and 100 U/ml Benzonase® (i.e. 3,300 U). Mix completely and incubate at 37°C for 1.5 hr with shaking.
3. Add 0.1X volume of 5 M NaCl (i.e. 3.3 ml) and mix completely. Incubate at 37°C for 30 minutes with shaking.
4. Centrifuge the mixture at $4,100 \times g$ for 10 minutes to remove cell debris. Carefully transfer the AAV containing supernatant to a new sterile tube.
5. Store AAV stocks at -80°C.



Divide cultured cells 18-24 hours before transfection to ensure that cells are actively dividing at the time of transfection.



Do NOT allow the *TransIT-VirusGEN®* Reagent to incubate alone in complex formation solution > 5 min, i.e. if the reagent is pre-diluted, add DNA within 5 min for optimal complex formation.

Do NOT agitate Reagent:Enhancer:DNA complexes after the initial mixing. This will result in decreased titer.



There is no need to change culture medium after transfection, unless required by your cell type or culture conditions.



Benzonase® is a non-specific endonuclease used to liberate virus particles from residual nucleic acids in the cell lysates and increase AAV titers.

TROUBLESHOOTING GUIDE

POOR DNA TRANSFECTION EFFICIENCY	
Problem	Solution
Incorrect vector sequence	If you do not observe expression of your target insert, verify the sequence of your plasmid DNA.
Suboptimal <i>TransIT</i> ® Reagent: <i>RevIT</i> ™:DNA ratio	Determine the best <i>TransIT</i> -VirusGEN® Reagent: <i>RevIT</i> ™ AAV Enhancer:DNA ratio for each cell type. Titrate the <i>TransIT</i> -VirusGEN® Reagent volume from 1-3 µl per 1 µg DNA. Titrate the <i>RevIT</i> ™ AAV Enhancer volume from 0.5-1.5 µl per 1 ml of culture. Refer to “Before You Start” on Page 2 for recommended starting conditions.
Suboptimal DNA concentration	Determine the DNA concentration accurately. Use plasmid DNA preps with an $A_{260/280}$ of 1.8-2.0. The optimal DNA concentration generally ranges between 0.5-2 µg per 1 ml of culture. Start with 2 µg DNA per 1 ml of culture. Consider testing different amounts of DNA while scaling the amount of <i>TransIT</i> -VirusGEN® accordingly.
Low-quality plasmid DNA	Use highly purified, sterile, endotoxin- and contaminant-free DNA for transfection. We recommend using Mirus MiraCLEAN® Endotoxin Removal Kit (MIR 5900) for removal of endotoxin from your DNA preparation. Alternatively, use cesium chloride gradient or anion exchange purified DNA which contains levels of endotoxin that do not harm most cells.
Cells not actively dividing at the time of transfection	Divide the culture at least 18-24 hours before transfection to ensure that the cells are actively dividing and reach optimal cell density at time of transfection. DO NOT proceed with transfection if cells are not doubling normally or are < 95% viable by trypan blue exclusion.
Time of AAV harvest not optimal	Determine the optimal time to harvest AAV post-transfection. Though typically 48-72 hours post-transfection, the best time to harvest will depend on the vector construct and production platform.
<i>TransIT</i> -VirusGEN® was not mixed properly	Warm <i>TransIT</i> -VirusGEN® Reagent to room temperature and vortex gently before each use. If <i>TransIT</i> -VirusGEN® Reagent is pre-diluted in complex formation solution, DNA should be added within 5 min. Incubating the <i>TransIT</i> -VirusGEN® Reagent in complex formation solution alone for an extended time results in reduced production of functional virus.
Disruption of transfection complex formation	After initial mixing of DNA, <i>TransIT</i> -VirusGEN® Reagent and <i>RevIT</i> ™ AAV Enhancer, do not agitate Reagent:Enhancer:DNA complexes again, e.g. do not vortex or invert before adding to cultures.
Precipitate formation during transfection complex formation	During complex formation, scale all reagents according to the table in the protocol, including serum-free media, <i>TransIT</i> -VirusGEN® Reagent, <i>RevIT</i> ™ AAV Enhancer and plasmid DNA. Precipitation may be observed when excess DNA is used during complex formation. This may negatively impact transfection efficiency. To avoid precipitation when using high concentrations of DNA, increase the volume of serum-free medium during complex formation by two-fold. Large-volume transfection complexes may appear turbid – typically, this phenomenon does <i>not</i> negatively impact transfection as long as complexes are well mixed.
Proper experimental controls were not included	To assess delivery efficiency of plasmid DNA, use Mirus <i>Label IT</i> ® Tracker™ Intracellular Nucleic Acid Localization Kit to label the target plasmid or use Mirus pre-labeled <i>Label IT</i> ® Plasmid Delivery Controls (please refer to Related Products on Page 7). To verify efficient transfection, use <i>TransIT</i> -VirusGEN® Reagent to deliver a positive control such as a luciferase, beta-galactosidase or green fluorescent protein (GFP) encoding plasmid.

TROUBLESHOOTING GUIDE continued

HIGH CELLULAR TOXICITY	
Problem	Solution
Cell density not optimal at time of transfection	High toxicity and cell death may be observed if cells are not dense at the time of transfection. For high virus titers using <i>TransIT</i> -VirusGEN® Reagent, ensure that cell cultures are approximately 3×10^6 cells/ml (for suspension cell transfections) at the time of transfection.
Cell morphology has changed	When generating AAV with <i>RevIT</i> ™ AAV Enhancer, cell growth may decrease. This is normal and does not adversely affect virus titers.
	Mycoplasma contamination can alter cell morphology and affect transfection efficiency. Check your cells for mycoplasma contamination. Use a fresh frozen stock of cells or use appropriate antibiotics to eliminate mycoplasma.
	A high or low cell passage number can make cells more sensitive and refractory to transfection. Maintain adherent or suspension HEK 293 cells below passage 30 for optimal recombinant virus production.
Transfection complexes not evenly distributed after complex addition to cells	Add transfection complexes while swirling the flask. If this is not possible, gently mix the culture vessel to ensure even distribution of the transfection complexes. However, avoid vigorous agitation that could disturb formed transfection complexes, e.g. vortexing after the initial mixing of the DNA, enhancer and transfection reagent.

RELATED PRODUCTS

- *TransIT*-VirusGEN® GMP Transfection Reagent
- VirusGEN® AAV Transfection Kit
- VirusGEN® GMP AAV Transfection Kit
- *Label IT*® Plasmid Delivery Controls
- *Label IT*® Tracker™ Intracellular Nucleic Acid Localization Kits
- MiraCLEAN® Endotoxin Removal Kits
- Ingenio® Electroporation Solution and Kits

For details on the above-mentioned products, visit www.mirusbio.com



Reagent Agent®

Reagent Agent® is an online tool designed to help determine the best solution for nucleic acid delivery based on in-house data, customer feedback and citations.

Learn more at:
www.mirusbio.com/ra

Contact Mirus Bio for additional information.



Mirus Bio LLC
5602 Research Park Blvd, Ste 210
Madison, WI 53719
Toll-free: 888.530.0801
Direct: 608.441.2852
Fax: 608.441.2849

©1996-2023 All rights reserved. Mirus Bio LLC. All trademarks are the property of their respective owners.
For terms and conditions, visit www.mirusbio.com